

Trickstuff Centerlock® Adaptor Sternschnuppe Mk III

We thank you for purchasing the original Trickstuff Sternschnuppe Mk III. This is a thoroughly engineered, lightweight Centerlock® adaptor.

It features an extraordinary big pressure surface to avoid warping of the disc rotor. The outer toothing fits all current axle standards:

- 9 and 10 millimeter quick release axle
- 12, 15 or 20 millimeter through axle

Installation of Sternschnuppe Mk III

Attention: *Sternschnuppe Mk III is a safety relevant part of your brake system. If you were not sure on how to handle the installation and periodic checks or if you did not have the necessary tools please address to an experienced bicycle mechanic.*

Check space between Sternschnuppe and fork/chainstay/seatstay before tightening the axle.

1. Slide the Sternschnuppe body with the chamfered side towards the hub on the toothed hub profile.
2. Place the disc rotor with its six holes on the Sternschnuppe body and slide the bolted ring through the six holes into the body.
3. Screw on the lock ring by hand. Fix the lock ring with a Shimano Hollowtech 2 tool.

NOTE: In order to avoid slipping off place the tool with its sharp edge towards the lock ring and its rounded edge to the outside. Press the tool by hand towards the lock ring while fixing the lock ring with force.

Torque: 30Nm (maximum 40Nm)

Check the torque after 20kms, then periodically every time when servicing your bike.

If there were any questions or problems please address to Trickstuff or your dealer.

Trickstuff GmbH
Zum Baumgarten 6
D-79249 Freiburg-Merzhausen
Phone: +49 (0)761 / 707 41 92
info@trickstuff.de
www.trickstuff.de